| DNS Server Setup Report using BIND on Linux   |
|---|
| Name: Tareq Suliman   |
| Title: Setting Up a DNS Server Using BIND   |
|   |
| Objective:  |
| To successfully deploy a DNS server on a Linux system that resolves domain names (e.g.,       |
| example.local) to IP addresses.   |
| 1. System Update  |
| Commands:   |
| sudo apt update   |
| sudo apt upgrade  |
| Explanation:  |
| This step ensures that the system's package list and installed software are up-to-date before |
| installation.   |
| 2. Install BIND   |
| Command:  |
| sudo apt install bind9  |
| Explanation:  |
| BIND9 is the most commonly used DNS server software for Linux systems.                        |
| 3. Configure BIND   |
| Command:  |
| sudo vim /etc/bind/named conf local   |

```
Added Configuration:
zone "example.local" {
   type master;
   file "/etc/bind/db.example.local";
}; Explanation: This configuration tells BIND to manage the 'example.local' zone and points it to
the zone file.
4. Create the Zone File
Command:
sudo vim /etc/bind/db.example.local
Zone File Content:
  $TTL 604800
@
       IN
             SOA
                    ns1.example.local. admin.example.local. (
             2023111001; Serial
             604800
                      ; Refresh
             86400
                      ; Retry
             2419200
                       ; Expire
             604800); Negative Cache TTL
 @
     @ IN
             NS
                    ns1.example.local.
```

## Explanation:

IN

IN

A A 192.168.1.10

192.168.1.10

ns1

Defines the zone's authoritative name server, A records for the domain and its name server, and sets TTL values.

## 5. Restart BIND

| Command:  |
|---|
| sudo service bind9 restart  |
| Explanation:  |
| Restarts the BIND service to apply all changes.   |
|   |
| 6. Update resolv.conf   |
| Command:  |
| sudo vim /etc/resolv.conf   |
| Added Line:   |
| nameserver 192.168.1.10   |
| Explanation:  |
| This directs the system to use the new DNS server (your server) for name resolution.            |
|   |
| 7. Test the DNS Server  |
| Command:  |
| nslookup example.local  |
| Expected Output:  |
| Server: 192.168.1.10  |
| Address: 192.168.1.10#53  |
| Name: example.local   |
| Address: 192.168.1.10   |
| Explanation:  |
| Verifies that the DNS server resolves example.local correctly.                                  |
|   |
| Conclusion:   |
| The DNS server using BIND was successfully configured. The domain 'example local' was correctly |

resolved to the assigned IP, confirming that the server is functioning properly.